


# Rexroth Oil Cleanliness Booklet



#### 2 Oil Cleanliness Booklet | Introduction

### Introduction

Oil is the central component of any hydraulic system. If a system fails, contamination is one of the major reasons. This booklet explains the basics of contamination control and serves as a reference and information tool.



#### 04 Need for Hydraulic Filtration

05 Sources of Problems with Fluid Systems

06 Classical Oil Analysis

07 MPC 4614 Mobile Particle Counter

08 Contamination – Types, Origin, Examples

12 Damage Caused By Contamination

13 The Objective

14 Filtration Grade - Particle Sizes

16 Achievable Oil Cleanliness in Accordance with ISO 4406

17 Overview of the Key Filter Properties

18 Fitting Tolerance of Hydraulic Components

19 Recommended Oil cleanliness level

20 Oil Cleanliness Codes in Accordance with ISO 4406

32 Fluid and Product Service

33 Fluidmanagement Products

41 Notes

# Need for Hydraulic Filtration




Inspecting contamination in hydraulic systems is a major aspect when designing a filter concept.



# Sources of Problems in Fluid Systems


More than ¾ of all problems can be traced back to contaminated oil. Monitoring oil cleanliness is therefore the most important factor in preventing system failures. Monitoring hardware only detects around 20 % of all unplanned downtimes.



# Oil Analysis

### Types of inspection for oil cleanliness

- Offline examination of oil samples in the laboratory
- Microscopic particle count in accordance with ISO 4407
- Gravimetric test in accordance with ISO 4405
- Microscopic determination of the type of contamination



### Mobile Particle Counter for Conducting Online Measurements of the Oil Cleanliness Class


- Light extinction principle
- Laser sensor
- Robust and reliable device with all basic functions
- Integrated battery pack and memory
- Oil cleanliness classes in accordance with ISO 4406 4 µm(c), 6 µm(c), 14 µm(c)
- Comprehensive range of accessories, e.g. printer, tank pump, external memory card
- Very easy to use







# Types of Contamination



1. Solid particles (abrasion and dirt)

#### **Consequences:**

- Initial damage through "scoring"
- Impact on control and regulation properties
- Component wear
- Component failure
- Reduction in machine availability

Measures: Filtration

#### 2. Liquid contamination (usually water, free and in solution)

#### **Consequences:**

- Corrosion, wear
- Impairment of viscosity
- ▶ Chem. reaction with the fluid
- Impact on lubricating properties
- Ageing (oxidation) of oil
- Poor filterability
- Reduction in filter service intervals
- Reduction in machine availability

#### Measures:

- Breather filters with AS filter material
- Water absorbing filter elements (free)
- Vacuum dehydrator (water in solution)

3. Gaseous contamination (air)

#### **Consequences:**

- ▶ Foam formation in the oil
- Inaccurate valve response
- Loss of energy
- Pump damage
- Chem. reaction with the fluid
- Oxidation
- Reduction in machine availability

#### Measures:

- Bleed system
- Seal pumps
- Use a vacuum dehydrator


# Sources of Contamination

### 1. Built-in contamination

- ► Foundry sand, dust
- Manufacturing residue:
  - Welding residue
  - Metal swarf
  - Blasting material, lacquer/paint particles
  - Preservation material
- Residue from cleaning agents (textile fibers)

### 2. External contamination

- Dirt from the ambient air, introduced via
  - Plunger rods
  - Labyrinth seals
  - Aeration
- Contamination caused by adding oil



# 3. Self-generated contamination

- Metallic wear caused by abrasion and erosion
- Seal abrasion
- Chemical corrosion
- Oil ageing products
- Oxidation residue
- Oil-insoluble substances caused by mixing oil

# Examples of residual dirt

### **Built-in contamination**

Residue from a return line filter (mobile hydraulic systems)


- Welding residue
- Metal swarf
- Paint residue
- Resin



# Self-generated contamination (wear)

Residue from a high-pressure filter in a hydraulic system within a stainless steel forging press

- Coarse brass and steel abrasion particles
- Severe sliding wear (grooves and stress marks)



# Damage Caused By Contamination

### Material removal (erosion)


caused by a high flow rate along edges combined with a high number of ingressed dirt particles with high speed in the flow.



### Grooving (abrasion)

caused by hard, abrasive particles that are roughly the same size as the clearance of the components.


Consequence: Reduction in performance due to leaking oil.



# The Approach

### Prevent with Rexroth filter technology.

- Optimum oil cleanliness
- Reliable component protection
- Major contribution towards machine availability
- High degree of customer satisfaction



- High degree of oil contamination
- ▶ ISO 22/20/18

- Achievable oil cleanliness using fine filter elements
   ISO 12/10/8
- ► ISO 12/10/8

# Filtration Grade – Particle Sizes

Viruses 0,003 - 0,05 μm

 Image: Non-State
 Image: Non-State<

•


Tobacco smoke 0,01 – 1 μm

▲ Blood cells 0,5 – 1,5 µm

Bacteria 0,3 - 20 µm

▼ Pollen ~ 20 µm







Visibility limit = 40 μm

Particle sizes are measured in units called "micrometers". A micrometer is one millionth of a meter.

The visibility limit of the human eye is approx. 40  $\mu$ m. This means that particles that are the most hazardous to a hydraulic system cannot be detected with the naked eye.

# Achievable Oil Cleanliness in Accordance with ISO 4406

HydroClean XL filter material									
H20XL							19/1	6/12 - 22	/17/14
H10XL				17/1	4/1	0 - 21	/16/13		
H6XL		15/1:	2/1	0 - 19	/14	/11			
H3XL		13/10/	8 - 17/	13/	10				
H1XL	10/6/	/4 - 14/8/	6						

## Overview of the most important filter characteristics



#### **Filtration grade**

- Nominal (from manufacturer)
- "Absolute" in accordance with ISO 16889
- Mesh width for wire fabric


### **Dirt absorption capacity**

- ▶ In accordance with ISO 16889
- ISOMTD test dust

### **Differential pressure**

- ▶ In accordance with ISO 3968
- In relation to 30 cSt/25 µm

All three properties are mutually interdependent. Rexroth filter elements are characterized by an optimum ratio for these properties, ensuring the best possible filtering action with maximum dirt absorption and minimum  $\Delta p$ .



# Fitting Tolerance of Hydraulic Components

<b>Gear pump</b> Gear pump, Side plate Gear housing	0,5 - 5 μm 0,5 - 5 μm
<b>Vane pump</b> Vane tip Vane surfaces	0,5 - 5 μm 5 - 13 μm
<b>Piston pump</b> Piston bore Valve plate cylinder	5 - 40 μm 1,5 - 10 μm
<b>Servo valve</b> Control piston Baffle plate	18 - 63 μm 2,5 - 8 μm
<b>Control valve</b> Control piston Cone valve	2,5 - 23 μm 13 - 40 μm

Extract from CETOP RP 92H

Examinations show that even particles with sizes that are  $1/_3 x$  the clearance width can lead to the clearance becoming blocked. The filtration grade of the system filters should therefore be selected in such a way as to ensure the absolute filtration grade is smaller than or equal to  $1/_3$  of the smallest clearance width in the system.

### Filtration grade $\leq 1/3$ x smallest clearance

# Recommended Oil cleanliness level

Application	Oil cleanliness required in accordance with ISO 4406	Recommended filter material/ filtration grade
Systems with extremely high dirt sensitivity and very high availability requirements	≤ 16/12/9	H1XL/1µm
Systems with high dirt sensitivity and high availabi- lity requirements, such as servo valve technology	≤ 18/13/10	H3XL/3µm
Systems with proportional valves and pressures > 160 bar	≤ 19/14/11	H6XL/6µm
Vane pumps, piston pumps, piston engines	≤ 18/16/13	H10XL/10µm
Modern industrial hydraulic systems, directional valves, pressure valves	≤ 20/16/13	H10XL/10µm
Industrial hydraulic systems with large tolerances and low dirt sensitivity	≤ 21/17/14	H20XL/20µm

# Oil Cleanliness Codes in Accordance with ISO 4406 and Examples of Contamination

Number of participation (per 100 ml)	ISO- Code				
from	from to				
1.000.000	2.000.000	21			
500.000	1.000.000	20			
250.000	500.000	19			
130.000	250.000	18			
64.000	130.000	17			
32.000	64.000	16			
16.000	32.000	15			
8.000	16.000	14			
4.000	8.000	13			
2.000	4.000	12			
1.000	2.000	11			
500	1.000	10			
250	500	9			
130	250	8			
64	130	7			
32	64	6			
16	32	5			

#### **Classification of all particles**

≥ 4 µm(c), ≥ 6 µm(c) and ≥ 14 µm(c)

#### Example from ISO 18/16/11:


190.000 particles ≥ 4 μm(c)/100 ml 58.600 particles ≥ 6 μm(c)/100 ml 1.525 particles ≥ 14 μm(c)/100 ml

ISO 4406 counts particles accumulatively, i.e. all particles that are larger than or equal to 4  $\mu$ m. In contradiction to this, NAS 1638 counts the particles in differential size classes, i.e. all particles within the range of 5 - 15  $\mu$ m, 15 - 25  $\mu$ m, etc. NAS 1638 became INVALID on 05/30/2001!

The replacement standard SAE AS 4059 is a national standard intended for the US aviation industry only. It is therefore no longer permitted to specify contamination classes in accordance with NAS. Specifying contamination in accordance with ISO 4406 on the other hand is considered to be state-of-the-art.

### ISO 10/7/5

(NAS 1638: class 1)



Particle size		
≥ 4 µm(c)	≥ 6 µm(c)	≥ 14 µm(c)
Particle count		
500 to 1.000	64 to 130	16 to 32

### ISO 12/11/6


(NAS 1638: class 2)



Particle size			
≥ 4 µm(c)	≥ 6 µm(c)	≥ 14 µm(c)	
Particle count			
2.000 to 4.000	1.000 to 2.000	32 to 64	

### ISO 14/13/9


(NAS 1638: class 3)



Particle size		
≥ 4 µm(c)	≥ 6 µm(c)	≥ 14 µm(c)
Particle count		
8.000 to 16.000	4.000 to 8.000	250 to 500

### ISO 16/14/10


### (NAS 1638: class 5)



Particle size		
≥ 4 µm(c)	≥ 6 µm(c)	≥ 14 µm(c)
Particle count		
32.000 to 64.000	8.000 to 16.000	500 to 1.000

### ISO 17/15/13


(NAS 1638: class 6)



≥ 6 µm(c)	≥ 14 µm(c)
16.000 to 32.000	4.000 to 8.000

### ISO 18/16/13


(NAS 1638: class 7)



≥ 6 µm(c)	≥ 14 µm(c)
32.000 to 64.000	4.000 to 8.000
	1

### ISO 19/17/14


#### (NAS 1638: class 8)




≥ 6 µm(c)	≥ 14 µm(c)
64.000 to 130.000	8.000 to 16.000


### ISO 22/19/17

(NAS 1638: class 10)



≥ 6 µm(c)	≥ 14 µm(c)
250.000 to 500.000	64.000 to 130.000








Sliding wear, 500 x

Cutting wear, 100 x




#### 30 Oil Cleanliness Booklet | Examples of Contamination



Cutting wear, 500 x

Dark, shiny metal, 500 x






Copper particles, 500 x


Red iron oxide, 500 x





◄ Greasy/resinous residue, 500 x

Seal abrasion, 500 x



# Fluid and Product Service

- Oil analysis particles, water content, residual additives
- ► Filter element analysis
- System flushing and decontamination
- Advice on oil cleanliness and oil maintenance







# Extract from the product range





### **Oil Analysis Case**

- Contamination control for hydraulic fluids and lubricants
- With sampling equipment



### Sampling Equipment

 Safe and simple oil sampling from pressure lines and oil containers



#### **Laser Particle Counter**

- Measurement category: ISO 4406 oil cleanliness code
- SAE AS 4059 oil cleanliness code
- Measurement range: 4 - 21 µm(c) with optional printer and pump

Datasheet: 51430



### **Online Particle Monitor**

- Measurement category: ISO 4406 oil cleanliness code
- ▶ 4, 6, 14 and 21 µm(c)



### Online Water-Content Measuring Device

- Application: Online determination of water activity in hydraulic systems and lubricating oil
- Measurement range: 0 100 % of the saturation of water in oil
- With optional data memory, network or alarm module



### VacuClean® Oil Purification

- Operating data: End vacuum up to 50 mbar
- Oil flow rate: 20 l/min,
   5 50 l/min, 5 80 l/min

#### Products | Oil Cleanliness Booklet 37



### Offline Filter Units (portable, 2- and 4-wheel design)

- Volume flow: 10, 15, 30, 35, 50, 80 l/min.
- Filter type: 40 LE 0018, 7 SL 45, 7 SL 130, 40 FLE 0045, 40 FLE 0095, 40 FLE 0120
- Adjustable volume flow: 40 - 150 l/min.
- ▶ Filter type: 40 FLE 0270C



### Wide Product Range of Filterelements made of paper, metal and fiberglass

- ► Filtration grade: 1 1500 µm
- ▶ Filter area: 10 cm<sup>2</sup> 4,8 m<sup>2</sup>

Datasheet: 51420

#### 38 Oil Cleanliness Booklet | Products



#### **Inline Filter**

#### Datasheet:

 51400
 Type 40/100 LEN 0040 to 0400

 51401
 Type 40 FLEN 0160 to 1000

 51402
 Type 100 FLEN 0160 to 0630

 51403
 Type 16 FE 2500 to 7500

 51421
 Type 245 LEN 0040 to 0400

 51422
 Type 350 LEN 0040 to 0400

 51423
 Type 445 LEN 0040 to 1000



#### **Tank Mounted Filter**

Datasheet: 51424 Type 10 TEN 004 51425 Type 10 TEN 0160, 0250, 0400, 0630, 1000



### Duplex Filter/ Change-Over Inline Filter

#### Datasheet:

51406 Type 50/150 LDN 0040 to 0400 51407 Type 40 FLDKN 0063 to 0630 51408 Type 40 FLDN 0160 to 1001 51409 Type 100 FLDN 0160 to 1000 51410 Type 16 FD 2500 to 7500



### **Manifold Mounted Filter**

#### Datasheet:

 51417
 Type 450 PBFN 0040 to 1000

 51418
 Type 245 PSFN 0040 to 0400

 51419
 Type 350 PSFN 0040 to 1000

 51427
 Type 320 PZR 025, 075, 125



### Filter for Mobile Hydraulics

**Datasheet:** 51426 Type 7SL 30 to 260




### Filter for Process Engineering


Type 16 FKE 25/400 to 150/2500 Type 40 FKE 25/400 to 150/2500 Type 16 FKD 25/400 to 150/2500 Type 40 FKD 25/400 to 150/2500

Design coated in Steel and Stainless Steel


### Notice | Oil Cleanliness Booklet 41



### 42 Oil Cleanliness Booklet | Notice



### Notice | Oil Cleanliness Booklet 43





Bosch Rexroth Filtration Systems GmbH Hardtwaldstraße 43 68775 Ketsch Germany Phone +49 6202 603-0 Fax +49 6202 603-199 info-ket@boschrexroth.de www.boschrexroth.com/filter

The data specified above only serve to describe the product. As our products are constantly being further developed, no statements concerning a certain condition or suitability for a certain application can be derived from ourinformation. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

RE 08016/2011 © Bosch Rexroth AG 2011 Subject to revisions! Printed in Germany